

MADELEINE FLOORS

flooring revolution



SPPC




UNIFLOOR



WOODEN FLOORING, PVC PLANK FLOORING, CARPET
TILES, ARTIFICIAL GRASS WALL PANELS

Layers of Rigid Core Luxury Vinyl Flooring are:

1. UV coating
2. Wear Layer
3. Decore film
4. Rigid SPC core
5. Attached underlayment



What is SPC

- > SPC (Stone Plastic Composite) is an engineered luxury vinyl that combines limestone and stabilizers to create an extremely durable core. SPC flooring is up to the task in both residential and commercial settings.
- > SPC Wooden flooring is the very much popular option for floors in use today. The pattern enables a plethora of colours and grains to be displayed side by side
- > SPC flooring is very easy in installing as well. Any layment even can install the product. IT comes with unique Uniclic technology. This glueless locking technology for flooring works perfectly for both the long and short sides of the flooring panel. In addition to that, Uniclic is a locking system that is suitable for all types of materials starting from 3.2 mm.
- > SPC flooring is constructed in a way as Engineered wood that gives it greater stability and resistance to changes in temperature and humidity.
- > The Good part is that it looks like hardwood flooring because the top floor is real, but all the underneath is an SPC rigid core which makes the product more better for commercial and residential uses.

SPC core

SPC flooring contains a solid, waterproof core that won't ripple or swell no matter how much liquid you subject it to..


The core is ultra-dense with no foaming agents. You'll find it in traditional WPC flooring. It gives you slightly less softness underfoot, Although it makes the flooring extra durable and long lasting.

UNICLIC TECHNOLOGY

Uniclic was the first one-piece locking profile to be introduced to the market. Over the years it became the industry's favorite locking technology thanks to its unmatched production efficiency and technical performance.

There are many advantages of uniclic locking system that makes the product more easy and simple to use.

1. Uniclic is fast and simple
2. it has to be installed by an angular rotation movement.
3. can also be installed in a horizontal way by snapping the planks into each other.
4. no unwanted gaps or spaces between floorboards.
5. no height differences and a seamless joint
6. Uniclic profiles interlock very securely.
7. Ensured Long- Lasting Stability



Advantages of SPC vinyl tiles



100% Waterproof



Termite proof



Stain Resistant



Anti slip



Quick & Easy to install



Superior scratch resistance



Fire Resistant



Easy logistics



Pet friendly



Recyclable



Ecological



Reduce noise



Easy to clean

How to install the SPC Flooring?

Adjust row so end cut is not less than 8".

Use shims to allow 3/8" expansion gap between the planks and the walls, or stationary interior room objects, so there is room for normal expansion and movement.

Starting from the LEFT with the tongue facing the wall, carefully place the first board in place.

Align the next piece by overlapping the short end of the first board. Engage the short end at a 45° angle of the tongue and groove.

The board must be flat to engage completely. Tap lightly into place by using a rubber mallet and tapping block to firmly lock short end. Continue in this manner until reaching the final plank in the first row.

Cut the final board piece to length.

Begin the second row with the cutpiece from the first row. If the cut piece is shorter than 8" (20cm), do not use it. Instead, begin with a new board to the left as necessary to align the edges of the end joint of the first row.

Carefully push the board down until the tongue and groove lock together on the long side and ends.

Position the first board of the second row in place by angling it up slightly, pushing forward and interlocking the long side of the tongue. Slide the board to the left as necessary to align the edges of the end joint of the first row.

Carefully push the board down until the tongue and groove lock together on the long side and ends.

Install second board of the second row (same as step 4 above). Slide close to the end joint without touching it. Ensure board lays flat.

Attach a scrap piece of floor to bridge gap between ends of planks.


Tap firmly but gently on end joint with a rubber mallet and tapping block to fully engage short end. Before moving on the next board, ensure the end joints are flush and tight.

Install the remaining boards and rows in the same container.

Cut the last board to size. If necessary, complete the tight fit by tapping the board into place with a pull bar.

Whenever practical, use cut pieces from previous rows as the starter board to reduce waste.

Maintain 8" spacing between end joints after the first rows for best appearance.



COLLECTION



THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 422 (WHITE LIMBA WOOD)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 423 (TIGER WOOD)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 431 (DARK WALNUT)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 434 (EBONY WOOD)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 435 (OAK WOOD GREY)



THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 438 (MAHOGANY WOOD)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 440 (CARMEL BROWN)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 441 (CHESTNUT CHERRY)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 442 (BRUNETTE WOOD)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 446 (GLAMWOOD BEIGE)





MADELEINE FLOORS

flooring revolution



SPC



UNIFLOOR



WOODEN FLOORING, PVC PLANK FLOORING, CARPET
TILES, ARTIFICIAL GRASS WALL PANELS